




I.L. MOTORSPORT

# Installation Instructions


## Frame Rail Reinforcement Bar NC

NC0-0962



Picture 1


First please loosen screws 6 to 10 on picture 1 and remove the OEM metal cross. (Picture 1)  
Now install the frame rail reinforcement bar (Picture 2) and use the supplied allen M8 screws on positions 7 to 10 and use the OEM screw on position 6.



Copyright by I.L. Motorsport

Picture 2

Please check if all screws are tightend by torque-ing them to the specified value. (See torque table)



Picture 3

Torque specifications for the positions

6 → 7,8 – 11 Nm

7 → 17,7 – 26,5 Nm

8 → 17,7 – 26,5 Nm

9 → 17,7 – 26,5 Nm

10 → 17,7 – 26,5 Nm